

## G540 RPV SERIES



PATENTED

FasTest's G540 sleeve actuated Residual Pressure Valve (RPV) oxygen connector is simple to use with a no twist, no turn approach to filling. Simply connect onto your CGA 540 RPV valve and lock into place with a forward movement of the sleeve and you are ready to fill the medical or industrial oxygen cylinder in a matter of seconds.

- Connects to CGA 540 valve
- Specifically designed for self contained 540 medical cylinder and inverted rack filling
- Simple, one hand operation sleeve actuated
- Simplified design has fewer seals to maintain



Product Family	Connection Type	Connection Method	Application
G-Series	External Threads	Sleeve Actuated	Oxygen
Connects To	Pressure Rating (psi)	Termination	Weight
CGA 540	3600	see table below	27 ounces

Part Number	Termination	Housing	Seals	Replacement Seals
G540-041-SH	Straight Male	Stainless Steel/ Brass	Viton	SG540
G540-042-SH	Right Angle Female			

For EPDM seals add "E" to the part number. Example: G540-041-SHE

Additional configurations available, consult part number key or contact **FasTest**.